

### Lexic RCCBs

Earth leakage protection



Conform to IEC61008-1;

Compatible with prong-type supply busbars:

- AC type: detect AC component faults;
- A type: detect AC and DC component faults;
- Hpi type: enhanced immunity to unwanted tripping in environments with disturbances eg., DG sets, computers, printers, thyristors etc;

Modules In, A Sensitivity, mA Category Number Quantity/Pack  
**2-pole 230VAC, AC Type**

25	30	0086 06	1/60
40	30	0086 07	1/60
63	30	0086 08	1/60
25	100	0086 09	1/60
40	100	0086 10	1/60
63	100	0086 11	1/60
25	300	0086 12	1/60
40	300	0086 13	1/60
63	300	0086 14	1/60

**2-pole 230VAC, A Type**

63	300	6021 72	1/60
----	-----	---------	------

**2-pole 230VAC, Hpi-A Type**

25	30	6021 68	
40	30	6021 69	
63	30	6021 70	
80	30	0088 25	

### Lexic RCBOs-2 Pole-2 Modules

Earth leakage, overload and short circuit protection



Modules In, A Sensitivity, mA Category Number Quantity/Pack  
**4-pole 400VAC, AC Type**

25	30	6021 26	1/60
40	30	6021 27	1/60
63	30	6021 28	1/60
25	100	6021 29	1/60
40	100	6021 30	1/60
63	100	6021 31	1/60
25	300	6021 32	1/60
40	300	6021 33	1/60
63	300	6021 34	1/60

**4-pole 400VAC, A Type**

63	300	6021 67	1/60
----	-----	---------	------

**4-pole 400VAC, Hpi-A Type**

25	30	6021 64	1/60
40	30	6021 65	1/60
63	30	6021 66	1/60
80	30	0088 29	1/60

### Lexic RCBOs-2 Pole-2 Modules

Earth leakage, overload and short circuit protection

**230VAC, AC Type**

6	30	0078 60	1/60
10	30	0078 61	1/60
16	30	0078 63	1/60
20	30	0078 64	1/60
25	30	0078 65	1/60
32	30	0078 66	1/60
40	30	0078 67	1/60

**230V, Hpi Type**

25	30	0085 67	1/60
32	30	0085 68	1/60
40	30	0085 69	1/60

**230VAC, AC Type**

6	300	0078 71	1/60
10	300	0078 72	1/60
16	300	0078 74	1/60
20	300	0078 75	1/60
25	300	0078 76	1/60
32	300	0078 77	1/60
40	300	0078 78	1/60